Recording booth
air circulation is off

microphone
condenser or dynamic

Select polar pattern
Bass cut option
Attenuation option

No options on the dynamic

MIC input jacks (booth)

Inputs 1 to 3

Direct into UA Audio Interface

Console software
MIC input for track
48V only for Condenser mic

Set recording level
Set sample rate

Input 4
TL Audio Tube Preamp

Console software
Line input
No 48V phantom power

TL Audio Controls
MIC input
Attenuation option
Bass cut option

TL Audio controls
Set input level
Compressor option
Set output level

Console software
Set input level
Set sample rate

Adobe Auditon
Make a new multitrack session

Maintain sample rate
32 bit, Stereo Mix

Preferences/Audio Hardware
Set Input/Output to Universal Audio Thunderbolt
Buffer size 64

Create Mono track
Name track
Select Input for track

Record Arm Track
Check Level
Record